

exolife™



EXOGEAR™

Manual

Welcome

Thank you for purchasing the ExoLife™, the premier battery case for the iPhone 4. We hope that you enjoy the freedom that comes from hours of additional use between charges of your iPhone 4. Please read this manual carefully, in its entirety, as it contains important information concerning proper use of the ExoLife™.

The ExoLife™ is a sleek, protective exoskeleton for the iPhone 4, outfitted with a rechargeable battery, to give your iPhone the extra power that you need. The ExoLife™ serves two functions: POWER and PROTECTION. The lithium-ion polymer battery inside the ExoLife™ virtually doubles the battery life of your iPhone so you can talk, surf, watch and play longer. And there is no need to sacrifice the beauty of your iPhone with some

clumsy looking case - the hardshell casing of the ExoLife™ wraps snugly around your iPhone to give it maximum protection while enhancing the look and feel of the iPhone itself.

In addition, the ExoLife™ offers 3 features: ExoClear™ technology that eliminates signal interference with your phone, ExoSave™ intelligent battery technology that automatically turns off the ExoLife™ when it is not needed and ExoSync™ for quick, easy and precise syncing with your iTunes. The ExoLife™ is designed specifically for the iPhone 4. For more information please visit us at: www.exogear.com

Package Contents

- (1) ExoLife™ battery case
- (2) USB 2.0 cable
- (3) Quick Start Guide
- (4) User's Manual

Compatability

Made for iPhone 4

Specifications

Dimensions:	2.44 x 5.1 x 0.59in 62 x 129.5 x 14.9mm
Weight:	2.08 oz (59 grams)
Battery Type:	Lithium-ion Polymer
Battery Power:	1 500mAh
Standby:	up to additional 300 hrs
Talk:	up to additional 7 hrs
Internet:	up to additional 6 hrs
Audio:	up to additional 40 hrs
Video:	up to additional 10 hrs

Features

- Sleek polycarbonate hard shell protects your iPhone from drops, bumps and scratches
- 1 500 mAh Lithium-Ion Polymer battery virtually doubles the life of your iPhone
- LED battery meter shows remaining battery life
- ExoClear™ technology eliminates

interference with your iPhone's antenna

- ExoSync™ ensures quick, easy and precise syncing with iTunes
- ExoSave™ intelligent battery technology automatically turns off the ExoLife™ when your iPhone is fully charged or when it is not in use to conserve battery life

How To Use The ExoLife™

For first time use: charge the ExoLife™ without the iPhone connected until fully charged (approx. 5 hours). To charge the ExoLife™, plug in the included USB cable into the ExoLife™ and plug the other end into your computer or the iPhone power adapter.

The LED lights will roll back and forth during the charging stage. When the ExoLife™ is fully charged, the battery status bars will be all lit and the power button will be lit as well.

How to charge the ExoLife™

1. Locate the USB Cover on the bottom of the ExoLife™. (It will be indicated by the USB symbol).
2. Open the cover
3. Connect the USB cable to the mini-USB port on the ExoLife™.
4. Connect the other end of the USB cable to your computer or iPhone power adapter.

(Note: you may charge the ExoLife™ with or without the iPhone connected).

How to turn on the ExoLife™

1. Press and hold the power button for 5 seconds. The status meter will light up from left to right and the power button will light up.

How to turn off the ExoLife™

1. Press and hold the power button for 5 seconds. The status meter will turn off from right to left and the power button will turn off.

How to check the battery life

1. Press and hold the power button for 2 seconds

How to read the battery meter

1. More than 75% = full bar
2. 50-75% = 3/4 bar
3. 25-50% = 1/2 bar_{TM}
4. Less than 25% = 1/4 bar
5. Less than 10% = blinking 1/4 bar

How to sync the iPhone with the ExoLifeTM connected

1. Connect the USB cable provided to the USB port on the ExoLife
2. Connect the other end of the USB cable to your computer
3. Open iTunes

User Tips

1. For maximum battery life, only turn the ExoLifeTM on when the iPhone battery is nearly depleted
2. Keep the ExoLifeTM dry and away from direct heat and sunlight

3. If you need to charge the iPhone and ExoLife™ quickly, remove the iPhone from the ExoLife™ and charge the iPhone and the ExoLife™ separately
4. If the ExoLife™ is on without being connected to the iPhone or being used by the iPhone, our ExoSave™ technology will turn off the ExoLife™ automatically

Troubleshooting/FAQ

How does ExoSave™ work?

ExoSave™ intelligent battery technology can determine when to turn off the ExoLife™ to conserve remaining battery power. This feature runs in the background without any interference or additional power consumption.

What's the best way to charge the ExoLife™ ?

For the quickest charge time, charge the iPhone and ExoLife™ separately.

Safety Instructions

Read all safety instructions and warnings thoroughly before using this product. Improper use of this product may result in damage to this or attached products, and/or cause excess heat, toxic fumes, fire, burns or explosion.

1. Do not disassemble the battery or attempt to recharge the battery outside of the case
2. Charge only using a USB 2.0 certified charging cable through the mini-USB port on the ExoLife™
3. Do not attempt to replace the battery
4. Do not crush, puncture, dispose of in fire, short the contacts or expose the battery to water or other liquids
5. Do not store or use the battery in a high temperature environment
6. Avoid excessive drops, bumps, abrasion and impact. If there is

any reason to believe that there is damage to the battery, discontinue use immediately. If you find that the battery is too hot, is emitting an odor is deformed, punctured or exhibits any suspicious or abnormal behavior, stop use immediately and contact EXOGEAR™

7. Always charge this battery before extended storage
8. Please dispose this and all batteries safely and in accordance with all applicable state and federal laws regarding proper battery disposal
9. Operating temperatures:
Charge: 32°F ~ 122°F
0°C ~ +50°C
Discharge: -4°F ~ 140°F
-20°C ~ +60°C
Storage temperature:
-4°F ~ 113°F, -20°C ~ + 45°C

Three-Year Limited Warranty

EXOGear™'s warranty obligations are limited to the terms set forth below:

EXOGear™ warrants that, subject to the following limitations, each of its products ("Product") will be free from defects in material and workmanship and conform to the Product specifications for a period of THREE (3) YEAR from the date of original retail purchase. This warranty applies only to Products manufactured by EXOGear™ that contain the "EXOGear™" trademark, trade name, or logo affixed thereon. Further, this warranty applies only to the original purchaser of the Product and all warranty claims must be accompanied by and submitted with a copy of the sales receipt.

EXOGear™ will have no liability for any Product returned if EXOGear™ determines that:

- The Product was not purchased from an authorized reseller.
- The person asserting the warranty is the not original purchaser of the Product.
- The asserted defect is attributable to misuse, abuse, mishandling, improper installation, alteration (including removing or obliterating labels), or accident while in the possession of someone other than EXOGear™.

- The Product's external casing was opened or if any of the internal components were exposed in any way.
- Any “wear and tear” of the Product.

Your exclusive remedy for any defective Product is limited to the repair or replacement of the defective Product. EXOGear™ may elect which remedy or combination of remedies to provide in its sole discretion. EXOGear™ shall have a reasonable time after determining that a defective Product exists to repair or replace a defective Product. EXOGear™'s replacement Product under its limited warranty will be manufactured from new and serviceable used parts. EXOGear™'s warranty applies to repaired or replaced Products for the balance of the applicable period of the original warranty or ninety days from the date of shipment of the repaired or replaced Product, whichever is longer.

There are no warranties that extend beyond the face of the EXOGear™ limited warranty. EXOGear™ disclaims all other warranties, express or implied, regarding the Products, including any implied warranties of merchantability, fitness or a particular purpose, or noninfringement. Some jurisdictions do not

allow the exclusion of the implied warranties. EXOGEAR™'s entire liability for any defective Product shall in no event exceed the purchase price of the defective Product. This limitation applies even if EXOGEAR™ cannot or does not repair or replace any defective Product and your exclusive remedy fails of its essential purpose.

EXOGEAR™ has no liability for general, consequential, incidental or special damages. These include loss of use of or damage to any other product used in conjunction with the defective Products, loss of recorded data, the cost of recovery of lost data, lost profits, downtime, loss of goodwill, damage to or replacement of equipment and property, the cost of the installation or removal of any Products, the installation of replacement Products, and any necessary inspection, testing, or redesign caused by any defect or by the repair or replacement of Products arising from a defect in any Product.

In the United States, some states do not allow exclusion or limitation of incidental or consequential damages, so the limitations above may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.